



INSTALLATION MANUAL

Before using your air conditioner, please read this manual carefully and keep it for future reference.

EDCM



ecox[®] SPLIT-TYPE ROOM AIR CONDITIONER

EDCM

Register your product at
www.ecoxline.com

f ecoxline @ecoxline



CONTENT

- 3** SAFETY PRECAUTIONS
- 3** WARNING
- 4** INSTALLATION INSTRUCTIONS
 - 4** Selecting installation place
 - 5** Accessories
 - 5** Indoor unit installation
 - 7** Outdoor unit installation
- 7** REFRIGERANT PIPE CONNECTION
- 8** ELECTRICAL WORK
- 10** AIR PURGING
- 11** Safety and leakage check
- 11** TEST RUNNING



CAUTION

- *Contact an authorized service technician for repair or maintenance of this unit*
- *Contact an authorized installer for installation of this unit.*
- *This appliance is not Intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.*
- *Children should be supervised to ensure that they do not play with the appliance.*
- *If the power cord is to be replaced, replacement work shall be performed by authorized personnel only.*
- *Installation work must be performed in accordance with the national wiring Standards by authorized personnel only.*



READ THIS MANUAL

- *Inside you will find many helpful hints on how to install and test the air conditioner property.*
- *Please read this Installation manual completely before installing the product.*
- *If the power cord is damaged, replacement work shall be performed by authorized personnel only.*
- *Installation work must be performed in accordance with the national wiring Standards by authorized personnel only.*

Contact an authorized service technician for repair, maintenance or installation of this unit.



SAFETY PRECAUTIONS

- Read the follow SAFETY PRECAUTIONS carefully before installation.

Electrical work must be installed by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model to be installed.

- Incorrect installation due to ignoring of the instruction will cause harm or damage.

■ The seriousness is classified by the following indications.



WARNING

This symbol indicates the possibility of death or serious injury.



CAUTION

This symbol indicates the possibility of Injury or damage to property

■ The items to be followed are classified by the symbols:



Symbol with background white denotes item that is PROHIBITED from doing.



WARNING

- 1 Engage dealer or specialist for installation. If installation done by the user is defective, it will cause water leakage, electrical shock fire.
- 2 Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock fire.
- 3 Use the attached accessories parts and specified parts for installation; otherwise, it will cause the set to fall, water, leakage, electrical shock fire.
- 4 Install at a strong and firm location which is able 10 withstands the set's weight. If the strength is not enough or installation is not property done, the set will drop and cause injury.
- 5 For electrical work, follow the local national wiring standard, regulation and this Installation Instructions. And independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock fire.
- 6 Use specified cable and connects tightly and clamp the cable so that no external force will be acted on the terminal. If the connection or fixing is not perfect, it will cause heat-up or fire at the connections.

7

Wiring routing must be properly arranged so that control boards cover is fixed properly. If control board cover is not fixed perfectly, it will cause heat-up at connection point of terminal, fire or electrical shock.



When carrying out piping connection, take care not to let air substances other than the specified refrigerant go into refrigeration cycle. Otherwise, it will cause lower capacity, abnormal high pressure in the refrigeration cycle, explosion and injury.



Do not modify the length of the power supply cord or use of extension cord, and do not share the single outlet with other electrical appliances. Otherwise, it will cause fire or electrical shock.



CAUTION

1

This equipment must be earthed and installed with earth leakage. It may cause electrical shock is grounding is not perfect.

2

Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.



Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.

SELECTING INSTALLATION PLACE

Select an installation location which is rigid and strong enough to support or hold the unit, and select location for easy maintenance. Read completely, then follow step by step.

INDOOR UNIT

- Do not expose the indoor unit to heat or steam.
- Select a place where there are no obstacles in front or around the unit.
- Make sure that condensation drainage can be conveniently routed away.
- Do not install near a doorway.
- Ensure the spaces indicated by arrows from the wall ceiling or other obstacles.
- A place where noise prevention is taken into consideration.
- A place 1m. or more to TV or radio instrument.
- A place where air circulation in the room is good.
- There should not be any direct sunlight. Otherwise, the sun will fade the plastic cabinet and affect its appearance. If unavoidable, sunlight prevention should be taken into consideration.

OUTDOOR UNIT

- If an awning is built over the outdoor unit to prevent direct sunlight or rain exposure, make sure that heat radiation from the condenser is not restricted.
- Keep the spaces indicated by arrows from wall or other obstacles.
- Do not place animals and plants in the path of the air inlet or outlet.
- Take the air conditioner weight into account and select a place where noise, vibration and hot air discharged will not be an issue.
- Do not install in a place full of machine oil or sulfide gas such as hot-spring resort.
- Do not install in a saline place such as coast.
- Do not install in a place where there are high frequency machines such as wireless equipment, welding machine or medical facility.




FIG.1




FIG.2

ROOFTOP INSTALLATION

If the outdoor unit is installed on a roof structure, be sure to level the unit.

Ensure the roof structure and anchoring method are adequate for the unit location.

Consult local codes regarding rooftop mounting.

ROOFTOP INSTALLATION


- | | |
|--|---------------------|
| ▶ Level gauge | ▶ Gas-leak detector |
| ▶ Screwdriver | ▶ Vacuum pump |
| ▶ Electric drill, Hole core drill
(Φ 65mm) | ▶ Gauge manifold |
| ▶ Flaring tool set | ▶ Users manual |
| ▶ Specified torque wrenches:
1.8 kgf.m,
4.2 kgf.m, 5.5 kgf.m,
6.6 kgf.m
(different depending on model No.) | ▶ Thermometer |
| | ▶ Multimeter |
| | ▶ Pipe cutter |
| | ▶ Measuring tape |
| ▶ Spanner (half union) | |
| ▶ Hexagonal wrench (4 mm) | |

ACCESSORIES

No.	Name of Accessories			Q'ty
1	Installation Plate			1
2	Clip Anchor			5-8 (dependeiong on model)
3	Self-tapping Screw A ST3.9x25			5-8 (dependeiong on model)
4	Seal (For cooling & heating models only)			1
5	Drain Joint (For cooling & heating models only)			1
6	Connecting pipe assembly	Liquid side	Φ 6.35	Parts you must purchase. Consult the dealer about the pope size.
			Φ 9.53	
		Gas side	Φ 9.53	
			Φ 12.7	
			Φ 16	
7	Remote controller			1



Except the above parts provided, the other parts needed during installation you must purchase.



- *Use a stud finder to locate studs to prevent unnecessary damage to the wall.*
- *A minimum pipe run of 3 meters is required to minimize vibration & excessive noise.*
- *Two of the A, B and C directions should be free from obstructions.*

- This Illustration is for explanation purposes only.
- Copper lines must be insulated Independently.

INDOOR UNIT INSTALLATION

1 Fit the installation Plato

- ① Fit the installation plate horizontally on structural parts of the wall with spaces around the installation plate.
- ② If the wall is made of brick, concrete or the like, drill eight (8) 5mm diameter holes in the wall insert Clip anchor for appropriate mounting screws.
- ③ Fit the installation plate on the wall with eight (8) type 'A' screws.



Fit the Installation Plate and drill holes in the wall according to the wall structure and corresponding mounting points on the installation plate. The Installation plate provided with the machine is different according to the models.

(Dimensions are in "mm" unless otherwise stated)




FIG. 4




FIG. 5

2 Drill a hole in the wall

- ① Determine hole positions according to the diagram detailed in Fig. 5. Drill one (1) hole (Φ65mm) slanting slightly to outdoor side.
- ② Always use wall hole conduit when drilling metal grid, metal plate or the like.





FIG. 6

3 Connective Pipe and Drainage Installation

Drainage

- 1 Run the drain hose sloping downward.
Do not install the drain hose as illustrated in Fig.7.
- 2 When connecting extension drain hose, insulate the connecting part of extension drain hose with a shield pipe, do not let the drain hose slack.



Connective pipe installation

- 1 For the left-hand and right-hand piping, remove the pipe cover from the side panel.
- 2 For the rear-right-hand and rear-left-hand piping, install the piping as shown.
- 3 Fix the end of the connective pipe. (Refer to Tightening Connection in REFRIGERANT PIPING CONNECTION).




FIG. 8

FIG. 9

4 Indoor unit Installation

- 1 Pass the piping through the hole in the wall.
- 2 Put the upper claw at the back of the indoor unit on the upper hook of the installation plate, move the indoor unit from side to side to see that it is securely hooked (see Fig.10 & Fig.11).
- 3 Piping can easily be made by lifting the indoor unit with a cushioning material between the Indoor unit and the wall. Get it out after finish piping.
- 4 Push the lower part of the Indoor unit up on the wall, then move the Indoor unit from side to side, up and down to check if it is hooked securely.




FIG. 10




FIG. 11

5 Piping and wrapping

Bundle the tubing, connecting cable, and drain hose with tape securely, evenly as shown in Fig.12

- Because the condensed water from rear of the indoor unit is gathered in ponding box and is piped out of room. Do not put anything else in the box.




FIG. 12



CAUTION

- Connect the indoor unit first, then the outdoor unit.
- Do not allow the piping to let out from the back of the indoor unit.
- Be careful not to let the drain hose slack.
- Heat insulated both of the auxiliary piping.
- Be sure that the drain hose is located at the lowest side of the bundle. Locating at the upper side can cause drain pan to overflow inside the unit.
- Never intercross nor intertwist the power wire with any other wiring.
- Run the drain hose sloped downward to drain out the condensed water smoothly.




FIG. 13

OUTDOOR UNIT INSTALLATION

Outdoor installations precaution

- Install the outdoor unit on a rigid base to prevent increasing noise level and vibration.
- Determine the air outlet direction where the discharged air is not blocked. In the case that the installation place is exposed to strong wind such as a seaside, make sure the fan operating property by putting the unit lengthwise along the wall or using a dust or shield plates.
- Specially in windy area, install the unit, to prevent the admission of wind. If need suspending installation, the installation bracket should accord with technique requirement in the installation bracket diagram.
- The installation wall should be solid brick, concrete or the same intensity construction, or actions to reinforce, damping supporting should be taken. The connection between bracket and wall, bracket and the air conditioner should be firm, stable and reliable.
- Be sure there is no obstacle which block radiating air.

Settlement of outdoor unit

Anchor the outdoor unit with a bolt and nut o 10 or 8 tightly and horizontally on a concrete or rigid mount.

Outdoor unit dimensions mm (WxHxD)	Mounting dimensions	
	A(mm)	B(mm)
780x540x250	549	280
760x590x275	530	290
670x540x250	484	275
775x545x310	600	320
840x700x320	560	335
895x860x330	590	333


Drain joint installation



CAUTION

The drain joint is slightly different according to the different outdoor unit.

For the drain joint with the see (Fig.15 (A)), first fit the seal onto the drain joint, then insert the drain joint into the base pan hole of outdoor unit, rotate 90° to securely assemble them. To install drain joint as shown in Fig.15 (B), insert the drain joint into the base pan hole of outdoor unit until it remains fixed with a clicking sound. Connecting the drain joint with an extension drain hose (Locally purchased), in case of the water draining off the outdoor unit during the heating mode.



REFRIGERATN PIPE CONNECTION

1 Flaring work

Main cause for refrigerant leakage is due to defect in the flaring work. Carry out correct flaring work using the following procedure.

(A) Cut the pipes and cable.

- 1 Use the piping kit accessory or pipes purchased locally.
- 2 Measure the distance between the indoor and the outdoor unit.
- 3 Cut the pipes a little longer than the measure distance.
- 4 Cut the cable 1.5m longer than the pipe length.

(B) Burr removal

- 1 Completely remove all burrs from the cut cross section of pipe/tube.
- 2 Put the end of the copper tube/pipe in a downward direction as you remove burrs in order to avoid dropping burrs into the tubing.

(C) Putting nut on

Remove flare nuts attached to indoor and outdoor unit, then put them on pipe/tube having completed burr removal (not possible to put them on after flaring work).

(D) Flaring work

Firmly hold copper pipe in a die in the dimension shown in the table below.




FIG. 14




FIG. 16




FIG. 17

Outer diam. (mm)	A(mm)	
	Max.	Min.
Φ 6.35	1.3	0.7
Φ 9.52	1.6	1.0
Φ 12.7	1.8	1.0
Φ 16	2.4	2.2

Tightening Connection

- Align the center of the pipes.
- Sufficiently tighten the flare nut with finger, and then tighten it with a spanner and torque wrench as shown in Fig. 20 & 21.

Out Diameter (mm)	Tightening Torque (N.cm)	Additional Tightening Torque (N.cm)
Φ 6.35	1570 (160kgf.cm)	1960 (200kgf.cm)
Φ 9.52	2940 (300kgf.cm)	3430 (350kgf.cm)
Φ 12.7	4900 (500kgf.cm)	5390 (550kgf.cm)

FIG. 18



FIG. 19




FIG. 20





FIG. 21



CAUTION

Excessive torque can break nut depending on installations conditions.

ELECTRICAL WORK

Electric safety regulations for the initial installation

- If there is serious safety problem about the power supply, the technicians should refuse to install the air conditioner and explain to the client until the problem is solved.
- Power voltage should be in the range of 90%~110% of rated voltage.
- The creepage protector and main power switch with a 1.5 times capacity of Max. Current of the unit should be installed in power circuit.
- Ensure the air conditioner is grounded well.
- According to the attached Electrical Connection Diagram located on the panel of the outdoor unit to connect the wire.
- All wiring must comply with local and national electrical codes and be installed by qualified and skilled electricians.
- An individual branch circuit and single receptacle used only for this air conditioner must be available. See the following table for suggested wire sizes and fuse specifications:

Minimum nominal cross-sectional area of conductors:

Rated current of appliance (A)	Nominal cross-sectional area (mm ²)
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5



NOTE

The cable size and the current or the ruse or switch are determined by the maximum current indicated on the nameplate which located on the side panel or the unit Please refer to the nameplate before selecting the cable, ruse and switch.

CONNECT THE CABLE TO THE INDOOR UNIT




NOTE

Before performing any elecitrclal work, turn off the main power to the system.

- The inside and outside connecting cable can be connected without removing the front grille.
- The indoor power cord type is HO5VV-F or HO5V2V2-F, the outdoor power cord and interconnected cord type is HO7RN-F.

- 3 Lift the indoor unit panel up, remove the electrical box cover by loosening the screw as shown in Fig.22.
- 4 Ensure the color of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- 5 Wrap those cables not connected with terminals with insulation tapes, so that they will not touch any electrical components. Secure the cable into the control board with the cord clamp.



Terminal block of indoor unit




FIG. 22

Outdoor unit




FIG. 23A


CONNECT THE CABLE TO THE OUTDOOR UNIT

- 1 Remove the cover control from the unit by loosening the 3 screws. See Fig. 23.
- 2 Dismount caps on the conduit panel.
- 3 Temporarily mount the conduit tubes (not included) on the conduit panel.
- 4 Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
- 5 Ground the unit in accordance with local codes.
- 6 Be sure to size each wire allowing several inches longer than the required length for wiring.
- 7 Use lock nuts to secure the conduit tubes.



WARNING

- Be sure to comply with focal codes while running the wire from the indoor unit to the outdoor unit.
- Every wire must be connected firmly.
- No wire should be allowed to touch refrigerant tubing, the compressor or any moving parts.
- Loose wiring may cause the terminal to overheat or result in unit malfunction.
- A fire hazard may also exist. Therefore, be sure all wiring is tightly connected.
- Disconnecting means must be provided and shall be located within sight from and readily accessible from the air conditioner.
- Connecting cable with conduit shall go through the hole of the conduit panel.



NOTE

To prevent wires loosening or leaving the cord clamp, please select proper cord diameter to fill the holes on the cord clamp.

Terminal block of outdoor unit




FIG. 23B



CAUTION

After the confirmation or the above conditions, prepare the wiring as follows:

- ❶ Never fail to have an individual power circuit specifically for the air conditioner. As for the method of wiring, be guided by the circuit diagram posted on the inside of control cover.
- ❷ The screw which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened, (If they are loose, it could cause burn-out of the wires.)
- ❸ Specification of power source.
- ❹ Confirm that electrical capacity is sufficient.
- ❺ See to that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- ❻ Confirm that the cable thickness is as specified in the power source specification.
- ❼ Always install an earth leakage circuit breaker in a wet or moist area.
- ❽ **The following would be caused by voltage drop.**
Vibration of a magnetic switch, which will damage the contact point, fuse breaking, disturbance of the normal function of the overload.
- ❾ The means for disconnection from a power supply shall be incorporated in the fixed wiring and have an air gap contact separation of at least 3mm in each active (phase) conductors.

AIR PURPING

Air and moisture in the refrigerant system have undesirable effects as indicated below:

- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture In the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigeration system.

Therefore, the indoor unit and tubing between the indoor and outdoor unit must be leak tested and evacuated to remove any noncondensables and moisture from the system.

AIR PURPING WITH VACUUM PUMP

- **Preparation**
Check that each tube (both liquid and gas side tubes) between the indoor and outdoor units have been properly connected and all wiring for the test run has been completed. Remove the service valve caps from both the gas and the liquid side on the outdoor unit. Note that both the liquid and the gas side service valves on the outdoor unit are kept closed at this stage.
- **Pipe length and refrigerant amount:**

Connective pipe length	Air purping method	Additional amount of refrigerant to be changed	
Less than 5m	Use vacuum pump		
More than 5m	Use vacuum pump	Liquid side: Φ 6.35 R410A: (Pipe length-5)x20g/m	Liquid side: Φ 9.53 R410A: (Pipe length-5)x40g/m

- When relocate the unit to another place, perform evacuation using vacuum pump.
- Make sure the refrigerant added into the air conditioner is liquid form in any case.
(Not applicable to the units adopt freon R22)

CAUTION in handling the packed valve

- Open the valve stem until it hits against the stopper. Do not try to open it further.
- Securely tighten the valve stem cap with a spanner or the like.
- Valve stem cap tightening torque (See tightening torque table in previous page).

FIG. 24





FIG. 25






FIG. 26

When using the Vacuum Pump

(For method of using a manifold valve, refer to its operation manual.)

- 1 Completely tighten the flare nuts, A, B, C, D, connect the manifold valve charge hose to a charge port of the low-pressure valve on the gas pipe side.
- 2 Connect the charge hose connection to the vacuum pump.
- 3 Fully open the handle Lo of the manifold valve.
- 4 Operate the vacuum pump to evacuate. After starting evacuation, slightly loose the flare nut of the Lo valve on the gas pipe side and check that the air is entering (Operation noise of the vacuum pump changes and a compound meter indicates 0 instead of minus).
- 5 After the evacuation is complete, fully close the handle Lo of the manifold valve and stop the operation of the vacuum pump. Make evacuation for 15 minutes or more and check that the compound meter indicates -76cmHg (-1x10⁵Pa).
- 6 Turn the stem of the packed valve B about 45° counter clockwise for 6-7 seconds after the gas coming out, then tighten the flare nut again. Make sure the pressure display in the pressure indicator is a little higher than the atmosphere pressure.
- 7 Remove the charge hose from the Low pressure charge hose.
- 8 Fully open the packed valve stems B and A.
- 9 Securely tighten the cap or the packed valve.

SAFETY AND LEAKAGE CHECK

Electrical safety check

Perform the electric safe check after completing installation:

- 1 **Grounding work**
After finishing grounding work, measure the grounding resistance by visual detection and grounding resistance tester. Make sure the grounding resistance is less than 4 Ω.
- 2 **Electrical leakage check (performing during test running)**
During test operation after finishing installation, the serviceman can use the electroprobe and multimeter to perform the electrical leakage check. Turn off the unit immediately if leakage happens. Check and find out the solution ways till the unit operate properly.

Gas leak check

- 1 **Soap water method**
Apply soap water or a liquid neutral detergent on the indoor unit connection or outdoor unit connections by a soft brush to check for leakage or the connecting points or the piping. If bubbles come out, the pipes have leak.
- 2 **Leak detector**
Use the leak detector to check for leakage.



CAUTION

A: Lo packed valve B: Hi packed valve
C and D are ends of Indoor unit connection.




FIG. 27

TEST RUNNING

Perform test operation after completing gas leak check at the flare nut connections and electrical safety check.

- Check that all tubing and wiring have been properly connected.
 - Check that the gas and liquid side service valves are fully open.
- 1 Connect the power, press the ON/OFF button on the remote controller to turn the unit on.
 - 2 Use the MODE button to select COOL, HEAT, AUTO and FAN to check if all the functions work well.
 - 3 When the ambient temperature is too low (lower than 17° C/ 62° F), the unit cannot be controlled by the remote controller to run at cooling mode, manual operation can be taken. Manual operation is used only when the remote controller is disable or maintenance necessary.
 - Hold the panel sides and lift the panel up to an angle until it remains fixed with a clicking sound.
 - Press the Manual control button to select the AUTO or COOL. the unit will operate under Forced AUTO or COOL mode (see User Manual for details).
 - 4 The test operation should last about 30 minutes.

